



CAPABILITY LIST
EMAR
(AER(EP).P-145)

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
1	7000605-90X	MS-702	MS-700/702	AUTOPILOT MODE SELECTOR	HONEYWELL	A09-1169-025
2	222-305-003-101	MS-702	MS-700/702	AUTOPILOT MODE SELECTOR	HONEYWELL	A09-1169-025
3	7000605-910	MS-700	MS-700/702	AUTOPILOT MODE SELECTOR	HONEYWELL	A09-1169-025
4	7000605-911	MS-700	MS-700/702	AUTOPILOT MODE SELECTOR	HONEYWELL	A09-1169-025
5	066-01072-000X	KR-87	KR-87	ADF TRANSCEIVER	BENDIX/KING	006-05184-0007
6	066-01072-0014	KR-87	KR-87	ADF TRANSCEIVER	BENDIX/KING	006-05184-0007
7	066-01072-0015	KR-87	KR-87	ADF TRANSCEIVER	BENDIX/KING	006-05184-0007
8	066-01072-0017	KR-87	KR-87	ADF TRANSCEIVER	BENDIX/KING	006-05184-0007
9	066-01077-0000	KDF-806	KDF 805/806	ADF TRANSCEIVER	BENDIX/KING	006-05511-0008
10	066-01077-0001	KDF-806	KDF 805/806	ADF TRANSCEIVER	BENDIX/KING	006-05511-0008
11	071-01210-00XX	KFS-586	KDF 805/806	ADF CONTROL PANEL	BENDIX/KING	006-05639-0004
12	071-1284-XX	KFS-586A	KDF 805/806	ADF CONTROL PANEL	BENDIX/KING	006-05624-0004
13	066-1047-00	KDF 805	KDF 805/806	ADF TRANSCEIVER	BENDIX/KING	006-05109-0004
14	066-1047-01	KDF 805	KDF 805/806	ADF TRANSCEIVER	BENDIX/KING	006-05109-0004
15	071-01217-000X	KDA-692	KDF 805/806	ADF ADAPTER	BENDIX/KING	006-05186-0000
16	622-2362-001	ADF-60A	ADF-60	ADF TRANSCEIVER	ROCKWELL COLLINS	523-0766184
17	622-6590-001	CAD-62	ADF-60	ADF CONTROL ADAPTER	ROCKWELL COLLINS	523-0773216
18	622-6590-002	CAD-62	ADF-60	ADF CONTROL ADAPTER	ROCKWELL COLLINS	523-0773216
19	622-6522-00X	CTL-62	ADF-60	ADF CONTROL PANEL	ROCKWELL COLLINS	523-0772495
20	622-7382-001	ADF-462	ADF-462	ADF TRANSCEIVER	ROCKWELL COLLINS	523-0773906
21	622-7382-101	ADF-462	ADF-462	ADF TRANSCEIVER	ROCKWELL COLLINS	523-0773906
22	622-7382-111	ADF-462	ADF-462	ADF TRANSCEIVER	ROCKWELL COLLINS	523-0773906
23	622-7383-001	ANT-462A	ADF-462	ADF ANTENNA	ROCKWELL COLLINS	523-0773906
24	622-7384-001	ANT-462B	ADF-462	ADF ANTENNA	ROCKWELL COLLINS	523-0773906
25	622-2091-XXX	RCR 650	ADF 650()	ADF TRANSCEIVER	R. COLLINS/PSI LABS	523-0766207
26	622-3587-00X	RCR 650A	ADF 650()	ADF TRANSCEIVER	R. COLLINS/PSI LABS	523-0766207
27	622-1334-001	VHF-20B	VHF 2X ()	VHF TRANSCEIVER	ROCKWELL COLLINS	523-0765213
28	622-1334-002	VHF-20B	VHF 2X ()	VHF TRANSCEIVER	ROCKWELL COLLINS	523-0765213
29	522-2599-00X	313N-5	VHF 2X ()	VHF CONTROL PANEL	ROCKWELL COLLINS	523-0756632
30	522-3617-00X	313N-5D	VHF 2X ()	VHF CONTROL PANEL	ROCKWELL COLLINS	523-0756632
31	622-4523-00X	CTL-20	VHF 2X ()	VHF CTRL PANEL	ROCKWELL COLLINS	523-0769247
32	622-4523-01X	CTL-20	VHF 2X ()	VHF CTRL PANEL	ROCKWELL COLLINS	523-0769247
33	622-4523-20X	CTL-20	VHF 2X ()	VHF CTRL PANEL	ROCKWELL COLLINS	523-0769247
34	622-4523-21X	CTL-20	VHF 2X ()	VHF CTRL PANEL	ROCKWELL COLLINS	523-0769247
35	622-6152-00X	VHF-22A	VHF 2X ()	VHF TRANSCEIVER	ROCKWELL COLLINS	523-0771854
36	522-3616-50X	313N-4D	VHF 2X ()	VHF CTRL PANEL	ROCKWELL COLLINS	523-0769408
37	822-1114-001	VHF-22D	VHF 2X ()	VHF TRANSCEIVER	ROCKWELL COLLINS	523-0771854
38	822-1114-021	VHF-22D	VHF 2X ()	VHF TRANSCEIVER	ROCKWELL COLLINS	523-0771854
39	822-1114-023	VHF-22D	VHF 2X ()	VHF TRANSCEIVER	ROCKWELL COLLINS	523-0771854
40	622-7292-XXX	VHF-422A	VHF-422 ()	VHF TRANSCEIVER	ROCKWELL COLLINS	523-0773785
41	622-7293-XXX	VHF-422B	VHF-422 ()	VHF TRANSCEIVER	ROCKWELL COLLINS	523-0773785
42	822-1115-00X	VHF-422C	VHF-422 ()	VHF TRANSCEIVER	ROCKWELL COLLINS	523-0773785
43	822-1116-001	VHF-422D	VHF-422 ()	VHF TRANSCEIVER	ROCKWELL COLLINS	523-0773785
44	46660-1000	RT-385A	RT-385A	VHF TRANSCEIVER	CESSNA-ARC/SIGMA TEK	7010407
45	46660-1100	RT-385A	RT-385A	VHF TRANSCEIVER	CESSNA-ARC/SIGMA TEK	7010407
46	01181	VHF-251A	VHF-251A	VHF TRANSCEIVER	R. COLLINS/PSI LABS	698753
47	064-01023-000X	KTR 908	KTR 908	VHF TRANSCEIVER	BENDIX/KING	006-15667-0009
48	064-01023-001X	KTR 908	KTR 908	VHF TRANSCEIVER	BENDIX/KING	006-15667-0009
49	071-01215-00XX	KFS 598	KTR 908	VHF CTRL PANEL	BENDIX/KING	006-15668-0009
50	071-01282-00XX	KFS 598A	KTR 908	VHF CTRL PANEL	BENDIX/KING	006-15669-0012
51	071-01576-0101	KFS 599B	KTR 908	VHF CTRL PANEL	BENDIX/KING	006-15634-0001
52	071-01576-1201	KFS 599B	KTR 908	VHF CTRL PANEL	BENDIX/KING	006-15634-0001
53	069-01024-000X	KX 155	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-05179-0009
54	069-01024-001X	KX 155	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-05179-0009
55	069-01024-0020	KX 155	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-05179-0009

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
56	069-01024-003X	KX 155	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-05179-0009
57	069-01024-004X	KX 155	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-05179-0009
58	069-01032-0101	KX 155A	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-15542-0002
59	069-01032-0201	KX 155A	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-15542-0002
60	069-01033-0101	KX 165A	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-15610-0000
61	069-01033-0201	KX 165A	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-15610-0000
62	069-1019-00	KX 175B	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-05053-0006
63	069-1019-01	KX 175BE	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-05053-0006
64	069-1019-05	KX 175B	KX 1X5()	COMM/NAV TRANSCEIVER	BENDIX/KING	006-05053-0006
65	064-01052-00XX	KY 96A	KY 9X	VHF TRANSCEIVER	BENDIX/KING	006-05674-0005
66	064-01051-00XX	KY 97A	KY 9X	VHF TRANSCEIVER	BENDIX/KING	006-05674-0005
67	064-1019-XX	KY 196	KY 196	COMM TRANSCEIVER	BENDIX/KING	006-05169-0004
68	064-01015-00XX	KTR 953	KHF 950	RECEIVER / EXCITER	BENDIX/KING	006-05381-0000
69	064-01017-00XX	KAC 952	KHF 950	POWER AMPLIFIER	BENDIX/KING	006-05380-0000
70	064-01016-00XX	KCU 951	KHF 950	CONTROL UNIT	BENDIX/KING	006-05379-0001
71	063-01007-0000	KTR 993	KHF 990	RECEIVER / EXCITER	BENDIX/KING	006-05589-0000
72	064-01029-0000	KAC 992	KHF 990	POWER AMPLIFIER	BENDIX/KING	006-05588-0000
73	064-01029-0001	KAC 992	KHF 990	POWER AMPLIFIER	BENDIX/KING	006-05588-0000
74	071-1274-0X	KFS 594	KHF 990	HF CONTROL UNIT	BENDIX/KING	006-05575-0000
75	522-1660-000	618T-3	618T-3	HF SSB Transceiver	ROCKWELL COLLINS	520-5970004
76	522-1660-03X	618T-3	618T-3	HF SSB Transceiver	ROCKWELL COLLINS	520-5970004
77	522-2457-0XX	714E-3	618T-3	HF Control Unit	ROCKWELL COLLINS	523-0759328
78	622-5962-001	628T - 3A	628T - 3A	HF SSB Transceiver	ROCKWELL COLLINS	523-0770675
79	522-3444-001	490T-1A	628T - 3A	HF Antenna coupler	ROCKWELL COLLINS	523-0756808
80	064-01076-010X	KTR 909B	KTR 909B	UHF Transceiver	BENDIX/KING	006-15548-0000
81	705494-801//A	RT-1051/ARC-150(V)	ARC-150(V)	UHF Transceiver	ELMER SPA	1619/E
82	RT-742/ARC-51BX	RT-742/ARC-51BX	RT-742/ARC-51BX	UHF, COMM TRANSCEIVER	AERITALIA	TM 11-5820-518-12
83	622-1239-XXX	VIR-31A	VIR 3X()	Navigation Receiver	ROCKWELL COLLINS	523-0764194
84	622-6137-001	VIR-32	VIR 3X()	Navigation Receiver	ROCKWELL COLLINS	523-0772819
85	622-6137-201	VIR-32	VIR 3X()	Navigation Receiver	ROCKWELL COLLINS	523-0772819
86	622-4524-XXX	CTL-30	VIR 3X()	NAV CTRL Panel	ROCKWELL COLLINS	523-0769247
87	622-4483-00X	IND-31C	VIR 3X()	NAV Indicator	ROCKWELL COLLINS	523-0769614
88	622-2080-00X	VIR-351	VIR 351	Navigation Receiver	ROCKWELL COLLINS	523-0766030
89	622-2080-01X	VIR-351	VIR 351	Navigation Receiver	ROCKWELL COLLINS	523-0766030
90	622-2080-11X	VIR-351	VIR 351	Navigation Receiver	ROCKWELL COLLINS	523-0766030
91	622-4478-001	IND-351A	VIR 351	Navigation Indicator	ROCKWELL COLLINS	523-0766030
92	622-2084-001	GLS-350	VIR 351	Glideslope receiver	ROCKWELL COLLINS	523-0766031
93	622-7194-001	VIR 432	VIR 432	Navigation Receiver	ROCKWELL COLLINS	523-0773863
94	622-7194-011	VIR 432	VIR 432	Navigation Receiver	ROCKWELL COLLINS	523-0773863
95	622-7194-101	VIR 432	VIR 432	Navigation Receiver	ROCKWELL COLLINS	523-0773863
96	622-7194-201	VIR 432	VIR 432	Navigation Receiver	ROCKWELL COLLINS	523-0773863
97	066-01130-0X0X	KN 40	KN 40	Navigation Receiver	BENDIX/KING	006-05637-0002
98	066-1067-0X	KN 53	KN 53	Navigation Receiver	BENDIX/KING	006-05191-0001
99	2592789-902	AM 6015/A	AM 6015/A	Electronic control amplifier	HONEYWELL	15-3132-01
100	066-01064-0000	KN 62	KN 6X()	DME	BENDIX/KING	006-05144-0006
101	066-01068-0001	KN 62A	KN 6X()	DME	BENDIX/KING	006-05144-0006
102	066-01068-0004	KN 62A	KN 6X()	DME	BENDIX/KING	006-05144-0006
103	066-01070-0001	KN 63	KN 6X()	DME	BENDIX/KING	006-05176-0001
104	066-01070-0000	KN 63	KN 6X()	DME	BENDIX/KING	006-05176-0001
105	066-01088-0000	KN 64	KN 6X()	DME	BENDIX/KING	006-05144-0006
106	066-01088-0001	KN 64	KN 6X()	DME	BENDIX/KING	006-05144-0006
107	066-01078-000X	KNR 634	KNR 634()	NAV transceiver	BENDIX/KING	006-15643-0012
108	066-01078-001X	KNR 634A	KNR 634()	NAV transceiver	BENDIX/KING	006-15644-0012
109	071-1283-XX	KFS 564A	KNR 634()	NAV control panel	BENDIX/KING	006-15646-0014; 006-15
110	071-1216-XX	KFS 564	KNR 634()	NAV control panel	BENDIX/KING	006-15645-0013

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
111	622-1233-001	DME-40	DME-40/42	DME	ROCKWELL COLLINS	523-0770174
112	622-1233-003	DME-40	DME-40/42	DME	ROCKWELL COLLINS	523-0770174
113	622-3919-001	IND-41A	DME-40/42	DME Indicator	ROCKWELL COLLINS	523-0770176
114	622-3919-002	IND-41A	DME-40/42	DME Indicator	ROCKWELL COLLINS	523-0770176
115	622-6263-001	DME-42	DME-40/42	DME	ROCKWELL COLLINS	523-0772458
116	622-6263-003	DME-42	DME-40/42	DME	ROCKWELL COLLINS	523-0772458
117	622-6524-00X	IND-42A	DME-40/42	DME Indicator	ROCKWELL COLLINS	523-0772463
118	622-7318-00X	IND-42C	DME-40/42	DME Indicator	ROCKWELL COLLINS	523-0772463
119	622-1234-00X	339F-12	DME-40/42	DME Indicator	ROCKWELL COLLINS	523-0770176
120	622-1234-01X	339F-12	DME-40/42	DME Indicator	ROCKWELL COLLINS	523-0770176
121	622-1234-103	339F-12	DME-40/42	DME Indicator	ROCKWELL COLLINS	523-0770176
122	622-1234-113	339F-12	DME-40/42	DME Indicator	ROCKWELL COLLINS	523-0770176
123	622-1234-313	339F-12	DME-40/42	DME Indicator	ROCKWELL COLLINS	523-0770176
124	622-3670-001	TCR-451	DME-450	DME Transceiver	R. COLLINS/PSI LABS	523-0767563
125	690109-1	TCR-451	DME-450	DME Transceiver	R. COLLINS/PSI LABS	523-0767563
126	622-3671-001	IND-450	DME-450	DME Indicator	R. COLLINS/PSI LABS	523-0767563
127	066-01066-000X	KDM 706	KDM 706 ()	DME	BENDIX/KING	006-15665-0009
128	066-01066-0011	KDM 706A	KDM 706 ()	DME	BENDIX/KING	006-15666-0009
129	066-01066-002X	KDM 706A	KDM 706 ()	DME	BENDIX/KING	006-15666-0009
130	066-01066-0031	KDM 706A	KDM 706 ()	DME	BENDIX/KING	006-15666-0009
131	066-01066-0035	KDM 706A	KDM 706 ()	DME	BENDIX/KING	006-15666-0009
132	066-01066-0041	KDM 706	KDM 706 ()	DME	BENDIX/KING	006-15665-0009
133	066-01093-00XX	KDM 7060	KDM 70X0	DME	BENDIX/KING	006-05561-0003
134	066-01094-00XX	KDM 7070	KDM 70X0	DME	BENDIX/KING	006-05561-0003
135	066-01069-000X	KDI 572/3	KDI 57X	DME Indicator	BENDIX/KING	006-05178-0001
136	066-01044-0000	KMR 675	KMR 675	Marker Beacon	BENDIX/KING	006-05093-0002
137	066-01055-00XX	KMA-24-(X)0	KMA2X ()	Marker Beacon	BENDIX/KING	006-05180-0001
138	066-01155-0101	KMA26	KMA2X ()	Marker Beacon	BENDIX/KING	006-15544-0001
139	066-01155-0201	KMA26	KMA2X ()	Marker Beacon	BENDIX/KING	006-15544-0001
140	066-01078-000X	KNR 634	KNR 634 ()	NAV transceiver	BENDIX/KING	006-15643-0012
141	066-01078-001X	KNR 634A	KNR 634 ()	NAV transceiver	BENDIX/KING	006-15644-0012
142	071-1283-XX	KFS 564A	KNR 634 ()	NAV control panel	BENDIX/KING	006-15646-0014; 006-15
143	071-1216-XX	KFS 564	KNR 634 ()	NAV control panel	BENDIX/KING	006-15645-0013
144	622-1270-001	TDR-90	TDR-90/94	ATC Transponder	ROCKWELL COLLINS	523-0765128
145	622-4527-00X	CTL-90	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0769247
146	622-4527-01X	CTL-90	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0769247
147	622-4527-020	CTL-90	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0769247
148	622-4527-021	CTL-90	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0769247
149	270-2436-0X0	613L-3	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0768765
150	270-2436-100	613L-3	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0768765
151	275175-104	613L-3	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0768765
152	275175-106	613L-3	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0768765
153	622-6590-001	CAD-62	TDR-90/94	XPDR CTRL adapter	ROCKWELL COLLINS	523-0773216
154	622-6590-002	CAD-62	TDR-90/94	XPDR CTRL adapter	ROCKWELL COLLINS	523-0773216
155	622-9352-00X	TDR-94	TDR-90/94	ATC Mode S Transponder	ROCKWELL COLLINS	523-0775652
156	622-9210-00X	TDR-94D	TDR-90/94	ATC Mode S Transponder	ROCKWELL COLLINS	523-0775997
157	622-4533-00X	CTL-91	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0769247
158	622-6591-001	ANT-42	TDR-90/94	XPDR Antenna	ROCKWELL COLLINS	523-0768765
159	622-7346-00X	CAD-870	TDR-90/94	XPDR CTRL adapter	ROCKWELL COLLINS	523-0774242
160	622-6523-XXX	CTL-92	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0772495
161	622-8740-XXX	CTL-92A	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0772495
162	622-9614-1XX	CTL-92T	TDR-90/94	XPDR CTRL Panel	ROCKWELL COLLINS	523-0773216
163	622-2092-XXX	TDR-950	TDR 950 ()	ATC Transponder	R. COLLINS/PSI LABS	523-0766469 (698704)
164	622-3004-XXX	TDR-950L	TDR 950 ()	ATC Transponder	R. COLLINS/PSI LABS	523-0766469 (698704)
165	066-01141-X101	KT 71	KT 7X ()	ATC Transponder	BENDIX/KING	006-05306-0003

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
166	066-1034-0X	KT 76/78	KT 7X ()	ATC Transponder	BENDIX/KING	006-05058-0002
167	066-1034-10	KT 78	KT 7X ()	ATC Transponder	BENDIX/KING	006-05058-0002
168	066-01062-000X	KT 76A	KT 7X ()	ATC Transponder	BENDIX/KING	006-05143-0008
169	066-01062-0010	KT 78A	KT 7X ()	ATC Transponder	BENDIX/KING	006-05143-0008
170	066-01062-0020	KT 78A	KT 7X ()	ATC Transponder	BENDIX/KING	006-05143-0008
171	066-01071-0000	KXP 756	KXP 755/6	ATC Transponder	BENDIX/KING	006-05198-0006
172	071-01192-000X	KFS 576	KXP 755/6	ATC CTRL Panel	BENDIX/KING	006-15717-0000
173	071-01192-001X	KFS 576	KXP 755/6	ATC CTRL Panel	BENDIX/KING	006-15717-0000
174	071-01192-0022	KFS 576	KXP 755/6	ATC CTRL Panel	BENDIX/KING	006-15717-0000
175	071-01192-0026	KFS 576	KXP 755/6	ATC CTRL Panel	BENDIX/KING	006-15717-0000
176	071-01276-0008	KFS 576A	KXP 755/6	ATC CTRL Panel	BENDIX/KING	006-05632-0001
177	071-01276-0009	KFS 576A	KXP 755/6	ATC CTRL Panel	BENDIX/KING	006-05632-0001
178	071-01276-001X	KFS 576A	KXP 755/6	ATC CTRL Panel	BENDIX/KING	006-05632-0001
179	071-01276-002X	KFS 576A	KXP 755/6	ATC CTRL Panel	BENDIX/KING	006-05632-0001
180	066-01041-0000	KXP 755	KXP 755/6	ATC CTRL Panel	BENDIX/KING	006-05100-0001
181	071-01043-0002	KFS 570B	KXP 755/6	ATC Transponder	BENDIX/KING	006-05100-0001
182	MI-585161-1	Primus 90wxd	Primus 90	Radar receiver-transmitter	HONEYWELL	IB8029066
183	MI-585161-2	Primus 90wxd	Primus 90	Radar receiver-transmitter	HONEYWELL	IB8029066
184	3713406-50X	Primus 90wxd	Primus 90	Radar receiver-transmitter	HONEYWELL	IB8029066
185	MI-585222-1	RT-3002	Primus 300 SL	Radar receiver-transmitter	HONEYWELL	IB8023113
186	3713878-502	RT-3001	Primus 300 SL	Radar receiver-transmitter	HONEYWELL	IB8029084
187	MI-585277-X	DI-2007	Primus 300 SL	Radar Indicator	HONEYWELL	IB8023112
188	MI-585224-X	AP-3001	Primus 300 SL	Antenna Pedestral	HONEYWELL	IB8029085
189	MI-585200	RT-4001	Primus 400	Radar receiver-transmitter	HONEYWELL	IB8029077
190	MI-585200-1	RT-4001	Primus 400	Radar receiver-transmitter	HONEYWELL	IB8029077
191	1719726-505	RT-4001	Primus 400	Radar receiver-transmitter	HONEYWELL	IB8029077
192	1719726-508	RT-4001	Primus 400	Radar receiver-transmitter	HONEYWELL	IB8029077
193	MI-585201-X	DI-4001	Primus 400	Radar Indicator	HONEYWELL	IB8029078
194	3713527-510	DI-4001	Primus 400	Radar Indicator	HONEYWELL	IB8029078
195	3713527-50X	DI-4001	Primus 400	Radar Indicator	HONEYWELL	IB8029078
196	MI-585300-X	RT-5001	Primus 500	Radar receiver-transmitter	HONEYWELL	IB8023147
197	1719726-506	RT-5001	Primus 500	Radar receiver-transmitter	HONEYWELL	IB8023147
198	1719726-507	RT-5001	Primus 500	Radar receiver-transmitter	HONEYWELL	IB8023147
199	1719726-511	RT-5001	Primus 500	Radar receiver-transmitter	HONEYWELL	IB8023147
200	MI-585301-X	DI-5001	Primus 500	Radar Indicator	HONEYWELL	IB8023119
201	1719694-50X	AP-5001	Primus 500	Antenna Pedestral	HONEYWELL	IB8023121
202	MI-585302	AP-5001	Primus 500	Antenna Pedestral	HONEYWELL	IB8023121
203	MI-585302-1	AP-5001	Primus 500	Antenna Pedestral	HONEYWELL	IB8023121
204	622-4021-001	WXT-200A	WXR-220/270	Radar receiver-transmitter	ROCKWELL COLLINS	523-0772442
205	622-5940-001	IND-220	WXR-220/270	Radar Indicator	ROCKWELL COLLINS	523-0772445
206	622-5940-002	IND-220	WXR-220/270	Radar Indicator	ROCKWELL COLLINS	523-0772445
207	622-2494-001	ANT-212	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441
208	622-2494-002	ANT-212	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441
209	622-4020-001	ANT-212D	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441
210	622-2495-001	ANT-210	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441
211	622-2495-002	ANT-210	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441
212	622-7444-001	ANT-310A	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441
213	622-6513-001	ANT-312A	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441
214	622-6333-001	ANT-318A	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441
215	622-5941-001	IND-270	WXR-220/270	Radar Indicator	ROCKWELL COLLINS	523-0772445
216	622-5941-002	IND-270	WXR-220/270	Radar Indicator	ROCKWELL COLLINS	523-0772445
217	622-2501-001	ANT-312	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441
218	622-7337-001	WXT-250B	WXR-220/270	Radar receiver-transmitter	ROCKWELL COLLINS	523-0773856
219	622-7337-002	WXT-250B	WXR-220/270	Radar receiver-transmitter	ROCKWELL COLLINS	523-0773856
220	622-2502-001	ANT-310	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
221	622-2504-001	ANT-318	WXR-220/270	Radar Antenna	ROCKWELL COLLINS	523-0772441
222	822-0416-001	IND-270A	WXR-220/270	Radar Indicator	ROCKWELL COLLINS	523-0772445
223	622-0416-002	IND-270A	WXR-220/270	Radar Indicator	ROCKWELL COLLINS	523-0772445
224	622-4022-001	WXT-250A	WXR-220/270	Radar receiver-transmitter	ROCKWELL COLLINS	523-0772442
225	364-5000-00X	DA-1203C	RDR-1300	Radar Antenna	TELEPHONICS	364-G775-CMM01
226	4000966-010X	RT-1301B	RDR-1300	Radar receiver-transmitter	TELEPHONICS	006-05958-0006
227	4000504-030X	DA-1203A	RDR-1300	Radar Antenna	TELEPHONICS	006-05953-0005
228	4000831-010X	RT 1401B	RDR-1400	Radar receiver-transmitter	TELEPHONICS	006-05342-0002
229	4000525-451X	AA-451XA	RDR-1400	Radar Antenna	TELEPHONICS	006-05953-0005
230	4000525-551X	AA-551XA	RDR-1400	Radar Antenna	TELEPHONICS	006-05953-0005
231	4001973-010X	RT-1501A	RDR-1500()	Radar receiver-transmitter	TELEPHONICS	006-15588-0000
232	4001973-0151	RT-1501A	RDR-1500()	Radar receiver-transmitter	TELEPHONICS	006-15590-0000
233	4001974-020X	IN-1502A	RDR-1500()	Radar Indicator	TELEPHONICS	006-15591-0000
234	632275-002	IN-1502A	RDR-1500()	Radar Indicator	TELEPHONICS(GALILEO)	006-15591-0000
235	8055613-020X	IN-1502B	RDR-1500()	Radar Indicator	TELEPHONICS	006-15591-0000
236	632500-XXX	IN-1502B	RDR-1500()	Radar Indicator	TELEPHONICS(GALIELO)	006-15591-0000
237	632490	CN-1506	RDR-1500()	Radar Control Panel	TELEPHONICS(GALIELO)	006-15591-0000
238	4001975-0301	DA-1503A	RDR-1500()	Rada Antenna	TELEPHONICS	006-15591-0000
239	632280-001	DA-1503A	RDR-1500()	Rada Antenna	TELEPHONICS(GALIELO)	006-15591-0000
240	632280-002	DA-1503A	RDR-1500()	Rada Antenna	TELEPHONICS(GALIELO)	006-15591-0000
241	4001976-07XX	IU-1507A	RDR-1500()	Radar Interface Unit	TELEPHONICS	006-15590-0000
242	071-01378-0000	RS-811A	RDS-81	Radar receiver-transmitter	BENDIX/KING	006-05997-0003
243	3614077-8101	RS-181A	RDS-82	Radar receiver-transmitter	BENDIX/KING	006-05913-0003
244	3614078-8201	IN-182	RDS-82	Radar Indicator	BENDIX/KING	006-05913-0003
245	3614078-8202	IN-182	RDS-82	Radar Indicator	BENDIX/KING	006-05913-0003
246	071-01519-0101	ART-2000	RDR-2000	Radar receiver-transmitter	HONEYWELL	006-05332-0003
247	066-03084-003X	IN-182A	RDR 2000	Radar Indicator	HONEYWELL	006-05913-0003
248	4004437-901	RT-220	RT-220	Radar Altimeter receiver-transmitter	HONEYWELL	09-3531-01
249	4004437-902	RT-220	RT-220	Radar Altimeter receiver-transmitter	HONEYWELL	09-3531-01
250	4004437-903	RT-220	RT-220	Radar Altimeter receiver-transmitter	HONEYWELL	09-3531-01
251	7001840-9XX	RT-300	AA-300	Radar Altimeter receiver-transmitter	HONEYWELL	A09-3531-010
252	7000839-9XX	RA-315	AA-300	Radar Altimeter indicator	HONEYWELL	A09-3531-007
253	109-0748-87-105	RA-315	AA-300	Radar Altimeter indicator	HONEYWELL	A09-3531-007
254	17MW1001-1	APN 198	APN 198	Rad-Alt receiver-transmitter	AERITALIA	AER. 12-17MW1001-1/2/3/4
255	17MW1001-2	APN 198	APN 198	Rad-Alt receiver-transmitter	AERITALIA	AER. 12-17MW1001-1/2/3/4
256	17MW1001-3	APN 198	APN 198	Rad-Alt receiver-transmitter	AERITALIA	AER. 12-17MW1001-1/2/3/4
257	17MW1001-4	APN 198	APN 198	Rad-Alt receiver-transmitter	AERITALIA	AER. 12-17MW1001-1/2/3/4
258	17MW1001-5	APN 198	APN 198	Rad-Alt receiver-transmitter	AERITALIA	MTCE 0085
259	066-01048-0000	KRA 405	KRA-405	Rad-Alt receiver-transmitter	BENDIX/KING	006-05104-0002
260	066-01048-0002	KRA 405	KRA-405	Rad-Alt receiver-transmitter	BENDIX/KING	006-05104-0002
261	066-01153-0101	KRA 405B	KRA-405	Rad-Alt receiver-transmitter	BENDIX/KING	006-15536-0006
262	066-01153-0202	KRA 405B	KRA-405	Rad-Alt receiver-transmitter	BENDIX/KING	006-15536-0006
263	066-01153-2001	KRA 405B	KRA-405	Rad-Alt receiver-transmitter	BENDIX/KING	006-15536-0006
264	066-01153-4001	KRA 405B	KRA-405	Rad-Alt receiver-transmitter	BENDIX/KING	006-15536-0006
265	066-01153-5001	KRA 405B	KRA-405	Rad-Alt receiver-transmitter	BENDIX/KING	006-15536-0006
266	066-03031-000X	KNI 415	KRA-405	Radar Altimeter indicator	BENDIX/KING	006-15660-0004
267	066-03044-000X	KNI 416	KRA-405	Radar Altimeter indicator	BENDIX/KING	006-15661-0004
268	066-01061-0001	KRA 10	KRA-10()	Rad-Alt receiver-transmitter	BENDIX/KING	006-05152-0003
269	066-01061-0002	KRA 10A	KRA-10()	Rad-Alt receiver-transmitter	BENDIX/KING	006-05152-0003
270	066-01061-0003	KRA 10A	KRA-10()	Rad-Alt receiver-transmitter	BENDIX/KING	006-05152-0003
271	066-01061-0000	KRA 10	KRA-10()	Rad-Alt receiver-transmitter	BENDIX/KING	006-05152-0003
272	066-03054-000X	KI 250	KRA-10()	Radar Altimeter indicator	BENDIX/KING	006-05203-0002
273	071-01147-0000	KA 133	KRA-10()	Radar Altimeter Converter	BENDIX/KING	006-05152-0003
274	622-2855-001	ALT-55B	ALT 5X()	Radar Altimeter receiver-transmitter	ROCKWELL COLLINS	523-0766793

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
275	622-2855-002	ALT-55B	ALT 5X()	Radar Altimeter receiver-transmitter	ROCKWELL COLLINS	523-0766793
276	622-2855-011	ALT-55B	ALT 5X()	Radar Altimeter receiver-transmitter	ROCKWELL COLLINS	523-0766793
277	622-2855-012	ALT-55B	ALT 5X()	Radar Altimeter receiver-transmitter	ROCKWELL COLLINS	523-0766793
278	622-3201-001	ALT-50A	ALT 5X()	Radar Altimeter receiver-transmitter	ROCKWELL COLLINS	523-0766818
279	622-3201-002	ALT-50A	ALT 5X()	Radar Altimeter receiver-transmitter	ROCKWELL COLLINS	523-0766818
280	622-3201-011	ALT-50A	ALT 5X()	Radar Altimeter receiver-transmitter	ROCKWELL COLLINS	523-0766818
281	622-3201-012	ALT-50A	ALT 5X()	Radar Altimeter receiver-transmitter	ROCKWELL COLLINS	523-0766818
282	622-2937-00X	ALI-55	ALT 5X()	Radar Altimeter Indicator	ROCKWELL COLLINS	523-0766793
283	622-2938-00X	ALI-55A	ALT 5X()	Radar Altimeter Indicator	ROCKWELL COLLINS	523-0766793
284	622-4160-00X	DRI-55	ALT 5X()	Radar Altimeter indicator	ROCKWELL COLLINS	523-0768424
285	622-4160-01X	DRI-55	ALT 5X()	Radar Altimeter indicator	ROCKWELL COLLINS	523-0768424
286	7000836-90X	AD-500()	AD-500()	Attitude Director Indicator	HONEYWELL	09-2113-03
287	7000836-91X	AD-500()/AR-500	AD-500()	Attitude Director Indicator	HONEYWELL	09-2113-03
288	7000836-92X	AD-500()	AD-500()	Attitude Director Indicator	HONEYWELL	09-2113-03
289	7001182-90X	AD-550	AD-550()	Attitude Director Indicator	HONEYWELL	A09-2113-004
290	7001182-91X	AD-550	AD-550()	Attitude Director Indicator	HONEYWELL	A09-2113-004
291	7000466-9XX	AD-650	AD-650()	Attitude Director Indicator	HONEYWELL	A09-2113-002
292	4020547-90X	AD-600	AD-600()	Attitude Director Indicator	HONEYWELL	09-2113-01
293	4002531-454	HZ-464	HZ-464	Attitude Director Indicator	HONEYWELL	09-3321-02
294	4002531-90X	HZ-464	HZ-464	Attitude Director Indicator	HONEYWELL	09-3321-02
295	38221-XX-XXX	38221	38221	Gyro Horizon	BADIN CROUZET (THALES)	34-29-07
296	38221-AA-M	38221	38221	Gyro Horizon	BADIN CROUZET (THALES)	34-29-07
297	38221-AB-M	38221	38221	Gyro Horizon	BADIN CROUZET (THALES)	34-29-07
298	8.249.031	38300A	38300	Gyro Horizon	AERITALIA	PTS 8.249.900-1/2/3/4
299	8.249.001	38300B	38300	Gyro Horizon	AERITALIA	PTS 8.249.900-1/2/3/4
300	8.249.007	38300	38300	Gyro Horizon	AERITALIA	PTS 8.249.900-1/2/3/4
301	8.249.009	38300	38300	Gyro Horizon	AERITALIA	PTS 8.249.900-1/2/3/4
302	71003C	38300B	38300	Gyro Horizon	AERITALIA	PTS 8.249.900-1/2/3/4
303	212-077-200-1	A301-6W	A301-6()	Audio Control System	ANDREA SYSTEM LLC	C46-5042-003
304	412-7511-13-(1XX)	A301-6W	A301-6()	Audio Control System	ANDREA SYSTEM LLC	C46-5042-003
305	A301-6R	A301-6R	A301-6()	Audio Control System	ANDREA SYSTEM LLC	C46-5042-003
306	A301-6NV	A301-6NV	A301-6()	Audio Control System	ANDREA SYSTEM LLC	C46-5042-003
307	212-077-200-105	A301-6WCR	A301-6()	Audio Control System	ANDREA SYSTEM LLC	C46-5042-003
308	109-0729-19-1	AG-06-1	AG-06-()	Audio Control System	GEMELLI SAS	M.M. 5/78
309	109-0729-19-3	AG-06-1A	AG-06-()	Audio Control System	GEMELLI SAS	M.M. 5/78
310	109-0900-05-101	AG-06-1C	AG-06-()	Audio Control System	GEMELLI SAS	M.M. 5/78
311	109-0729-46-1	1.101(A)	1.101(A)	Audio System	OCEM	1.101(A) MM
312	071-2007-00	KAA 455	KAA 455	Audio control System	BENIDX KING	006-05132-0004
313	071-2007-01	KAA 455	KAA 455	Audio control System	BENIDX KING	006-05132-0004
314	071-2007-02	KAA 455	KAA 455	Audio control System	BENIDX KING	006-05132-0004
315	071-1087-XX	KA 119	KAA 455	Audio Control panel	BENIDX KING	006-05132-0004
316	2592920-444	RD 444	RD-44/444/445	Horizontal Situation Indicator	HONEYWELL	A09-3321-06
317	2592920-445	RD 445	RD-44/444/445	Horizontal Situation Indicator	HONEYWELL	A09-3321-06
318	2592920-044	RD 44	RD-44/444/445	Horizontal Situation Indicator	HONEYWELL	A09-3321-06
319	2592920-901	RD 44	RD-44/444/445	Horizontal Situation Indicator	HONEYWELL	A09-3321-06
320	7002493-90X	RD 450	RD 450	Horizontal Situation Indicator	HONEYWELL	09-2138-01
321	7002493-910	RD 450	RD 450	Horizontal Situation Indicator	HONEYWELL	09-2138-01
322	7002493-911	RD 450	RD 450	Horizontal Situation Indicator	HONEYWELL	09-2138-01
323	7002493-912	RD 450	RD 450	Horizontal Situation Indicator	HONEYWELL	09-2138-01
324	4027170-90X	RD 500	RD 500	Horizontal Situation Indicator	HONEYWELL	09-2132-01
325	4029529-90X	RD 500A	RD 500	Horizontal Situation Indicator	HONEYWELL	09-2132-01
326	7001179-90X	RD 550	RD 550-()	Horizontal Situation Indicator	HONEYWELL	A09-2132-003
327	7001179-91X	RD 550	RD 550-()	Horizontal Situation Indicator	HONEYWELL	A09-2132-003
328	7001179-95X	RD 550A/B	RD 550-()	Horizontal Situation Indicator	HONEYWELL	A09-2132-003

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
329	7001179-96X	RD 550A/B	RD 550- ()	Horizontal Situation Indicator	HONEYWELL	A09-2132-003
330	7001179-97X	RD 550R	RD 550- ()	Horizontal Situation Indicator	HONEYWELL	A09-2132-003
331	4020553-90X	RD-600	RD-600- ()	Horizontal Situation Indicator	HONEYWELL	09-2139-01
332	4032211-90X	RD-600B	RD-600- ()	Horizontal Situation Indicator	HONEYWELL	09-2139-02
333	4025782-90X	RD-600A	RD-600- ()	Horizontal Situation Indicator	HONEYWELL	09-2139-01
334	7000469-9XX	RD-650 ()	RD-650 ()	Horizontal Situation Indicator	HONEYWELL	A09-2139-003
335	4026206-9XX	RI-X06 ()	RD-650 ()	Remote instrument controller	HONEYWELL	A09-2139-003
336	1925757-2	1925757-2	1925757-2	Horizontal Situation Indicator	BENDIX/KING	72-196
337	520-4230-XXX	HSI-423A	HSI-423A	H.S.I.	MOOG	HSI-423A MM
338	622-0555-00X	332C-10	332C 10	Radio Magnetic Indicator	ROCKWELL COLLINS	523-0767591
339	622-0555-010	332C-10	332C 10	Radio Magnetic Indicator	ROCKWELL COLLINS	523-0767591
340	622-0555-011	332C-10	332C 10	Radio Magnetic Indicator	ROCKWELL COLLINS	523-0767591
341	4002963-404	RH-404	RH-4X4	Radio magnetic Indicator	HONEYWELL	09-3321-10
342	4002963-444	RH-444	RH-4X4	Radio magnetic Indicator	HONEYWELL	09-3321-10
343	4002963-464	RH-464	RH-4X4	Radio magnetic Indicator	HONEYWELL	09-3321-10
344	1777213-XXX	C-6	C-6 ()	Compass Indicator	HONEYWELL	15-2151-01
345	1777214-823	C-6A	C-6 ()	Compass Indicator	HONEYWELL	15-2151-01
346	1778686-XXX	C-6D	C-6 ()	Compass Indicator	HONEYWELL	15-2151-01
347	1782993-XXX	C-6F	C-6 ()	Compass Indicator	HONEYWELL	15-2151-01
348	1783755-XXX	C-6H	C-6 ()	Compass Indicator	HONEYWELL	15-2151-01
349	1784389-XXX	C-6J	C-6 ()	Compass Indicator	HONEYWELL	15-2151-01
350	66453()	C-2	C-2	Compass transmitter	HONEYWELL	A09-3321-014
351	066-03008-000X	KI 20X	KI-200 (series)	Navigation Indicator	BENDIX/KING	006-05052-0002
352	066-03034-001X	KI 20X	KI-200 (series)	Navigation Indicator	BENDIX/KING	006-15636-0005
353	066-03034-002X	KI 20X	KI-200 (series)	Navigation Indicator	BENDIX/KING	006-05137-0005
354	066-03056-000X	KI 208/209	KI-200 (series)	Navigation Indicator	BENDIX/KING	006-05140-0005
355	066-03056-0010	KI 208A	KI-200 (series)	Navigation Indicator	BENDIX/KING	006-15543-0000
356	066-03056-0011	KI 209A	KI-200 (series)	Navigation Indicator	BENDIX/KING	006-15543-0000
357	066-03038-0000	KI 229	KI-200 (series)	Navigation Indicator	BENDIX/KING	006-05192-0000
358	066-03060-001X	KNI 582	KNI 500 (series)	Radio magnetic Indicator	BENDIX/KING	006-05193-0002
359	066-03046-001X	KI-525A	KI-525 ()	Pictorial Navigation Indicator	BENDIX/KING	006-15621-0007
360	066-03046-000X	KI-525A	KI-525 ()	Pictorial Navigation Indicator	BENDIX/KING	006-15621-0007
361	520-5160-00X	5160-X	5160 (series)	Course selector indicator	AERONETICS (MOOG)	5160 Series MM
362	520-5160-01X	5160-X	5160 (series)	Course selector indicator	AERONETICS (MOOG)	5160 Series MM
363	622-4938-00X	RMI-30	RMI 30	Radio Magnetic Indicator	ROCKWELL COLLINS	523-0769676
364	622-4938-02X	RMI-30	RMI 30	Radio Magnetic Indicator	ROCKWELL COLLINS	523-0769676
365	622-8613-0XX	BIA-32	RMI 30	Bearing interface adapter	ROCKWELL COLLINS	523-0775205
366	622-2506-00X	RMI-36	RMI 36	Radio Magnetic Indicator	ROCKWELL COLLINS	523-0766802
367	622-2506-01X	RMI-36	RMI 36	Radio Magnetic Indicator	ROCKWELL COLLINS	523-0766802
368	622-2506-10X	RMI-36	RMI 36	Radio Magnetic Indicator	ROCKWELL COLLINS	523-0766802
369	622-2506-110	RMI-36	RMI 36	Radio Magnetic Indicator	ROCKWELL COLLINS	523-0766802
370	622-2506-111	RMI-36	RMI 36	Radio Magnetic Indicator	ROCKWELL COLLINS	523-0766802
371	522-4945-001	323A-2G	PN 101	Pictorial Navigation Indicator	ROCKWELL COLLINS	523-0755824
372	522-3082-000	331A-3F	PN 101	Pictorial Navigation Indicator	ROCKWELL COLLINS	523-0755824
373	522-3082-001	331A-3F	PN 101	Pictorial Navigation Indicator	ROCKWELL COLLINS	523-0755824
374	522-3082-002	331A-3F	PN 101	Pictorial Navigation Indicator	ROCKWELL COLLINS	523-0755824
375	369-25119-1	331A-3F	PN 101	Pictorial Navigation Indicator	ROCKWELL COLLINS	523-0755824
376	522-3241-000	332E-4	PN 101	Pictorial Navigation Indicator	ROCKWELL COLLINS	523-0755824
377	2586077-7	CN-1141/ASN-75	2586077-7	DIRECTIONAL GYROSCOPE	AERITALIA	PTS 8.071.900-3
378	8.071.001	8.071.001	CN998B/ASN43	GYRO UNIT, DISPLACEMENT	AERITALIA	PTS 8.071.900-3
379	060-00015-0000	KG-102A	KG-102A	DIRECTIONAL GYRO	BENDIX/KING	006-15623-0007
380	060-00015-0001	KG-102A	KG-102A	DIRECTIONAL GYRO	BENDIX/KING	006-15623-0007
381	060-00015-0002	KG-102A	KG-102A	DIRECTIONAL GYRO	BENDIX/KING	006-15623-0007
382	071-01052-0000	KMT-112	KG-102A	MAGNETIC AZIMUTH TRANSMITTER	BENDIX/KING	006-15624-0007
383	071-01242-000X	KA-51B	KG-102A	SLAVING ACCESSORY	BENDIX/KING	006-15627-0007

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
384	071-01242-001X	KA-51B	KG-102A	SLAVING ACCESSORY	BENDIX/KING	006-15627-0007
385	2594484	FX-220	C 14()	Fklux Valve	HONEYWELL	A09-3321-014
386	RCA11A-XX	RCA 11A	RCA 11A	DIRECTIONAL GYRO INDICATOR	KELLY / R.C. ALLEN	1309
387	RCA 15AK	RCA 15AK	RCA 15()	DIRECTIONAL GYRO INDICATOR	KELLY / R.C. ALLEN	1318
388	RCA 15BK	RCA 15BK	RCA 15()	DIRECTIONAL GYRO INDICATOR	KELLY / R.C. ALLEN	1318
389	RCA 15C	RCA 15C	RCA 15()	DIRECTIONAL GYRO INDICATOR	KELLY / R.C. ALLEN	1318
390	103-0023-01	RCA 15CM	RCA 15()	DIRECTIONAL GYRO INDICATOR	KELLY / R.C. ALLEN	1318
391	RCA 15CM	RCA 15CM	RCA 15()	DIRECTIONAL GYRO INDICATOR	KELLY / R.C. ALLEN	1318
392	133696-01	2163J	2163J	TRANSMITTER, RATE GYRO	LEAR SIEGLER Inc.	T.O. 5F10-4-12-3/4
393	A2850-5	TRU 2A/A	TRU 2A/A	TRANSMITTER, RATE GYRO	KELLY MFG	1324
394	229-0236-000	332G-2	332G-2	RATE GYRO	ROCKWELL COLLINS	523-0755240
395	7007453-902	RG-204	RG-203/4	RATE GYRO	HONEYWELL	09-1146-19
396	4020576-901	RG-203	RG-203/4	RATE GYRO	HONEYWELL	09-1146-19
397	214-075-244-1	7125-2	7125-2	RATE GYRO	MIDLAND ROSS	MM-7125-1,-2
398	4020936-90X	TARSYN-555H	TARSYN	TARSYN-H THREE-AXIS	HONEYWELL	A09-3321-016
399	2593996-555	TARSYN-555	TARSYN	TARSYN THREE-AXIS	HONEYWELL	A09-3321-008
400	1964393-1	1964393-1	1964393-1	COMPASS COUPLER	Bendix	72-204
401	206-070-274-005	A5930-02	MD-4A	TURN & SLIP INDICATOR	KELLY / R.C. ALLEN	558
402	206-070-274-5	2800-6845N1L	MD-4A	TURN & SLIP INDICATOR	KELLY / R.C. ALLEN	558
403	MS-28041-2	MD-4A	MD-4A	TURN & SLIP INDICATOR	KELLY / R.C. ALLEN	558
404	A1615	MD-4A	MD-4A	TURN & SLIP INDICATOR	KELLY / R.C. ALLEN	558
405	MC-1	T4040-02	MD-4A	TURN & SLIP INDICATOR	KELLY / R.C. ALLEN	558
406	9551	9551	9551	TURN & SLIP INDICATOR	UNITED INSTRUMENTS Inc.	9500
407	9551B	9551B	9551	TURN & SLIP INDICATOR	UNITED INSTRUMENTS Inc.	9500
408	520-9100-XXX	DG-9100	DG-9100	DIRECTIONAL GYRO	MOOG	34-20-90
409	4021541-XXX	GH-14A	GH-14A	GYRO HORIZON	HONEYWELL	09-3231-05
410	7000788-1XX	GH-206	GH-206	GYRO HORIZON	HONEYWELL	A09-3231-006
411	36104-1L-11-A2	IS-250/ARN	3610X-()	INDICATORE, RADIO MAGNETIC	AERITALIA	AN 16-35ID250-3/4
412	36107-1T-17-A1	IS-250/ARN	3610X-()	INDICATORE, RADIO MAGNETIC	AERITALIA	AN 16-35ID250-3/4
413	36108-1L-11-A1	IS-250/ARN	3610X-()	INDICATORE, RADIO MAGNETIC	AERITALIA	AN 16-35ID250-3/4
414	36109-1L-11-A1	IS-250/ARN	3610X-()	INDICATORE, RADIO MAGNETIC	AERITALIA	AN 16-35ID250-3/4
415	36110-1T-17-B1	IS-250/ARN	3610X-()	INDICATORE, RADIO MAGNETIC	AERITALIA	AN 16-35ID250-3/4
416	36115-1T-17-A1	IS-250/ARN	3610X-()	INDICATORE, RADIO MAGNETIC	AERITALIA	AN 16-35ID250-3/4
417	36104-1L-11-A1	IS-250/ARN	3610X-()	INDICATORE, RADIO MAGNETIC	AERITALIA	AN 16-35ID250-3/4
418	36109-1L-11-A3	IS-250/ARN	3610X-()	INDICATORE, RADIO MAGNETIC	AERITALIA	AN 16-35ID250-3/4
419	254-XXX	AIM400/800	RMI 36 (Nota 3)	Slaved Gyro - RMI	EXTANT AEROSPACE	670-0001-001
420	293-XXX	AIM400/800	RMI 36 (Nota 3)	Slaved Gyro - RMI	EXTANT AEROSPACE	670-0001-001
421	289-XXX	AIM400/800	RMI 36 (Nota 3)	Slaved Gyro - RMI	EXTANT AEROSPACE	670-0001-001
422	299-1X	AIM400/800	RMI 36 (Nota 3)	Slaved Gyro - RMI	EXTANT AEROSPACE	670-0001-001
423	297-XXX	AIM400/800	RMI 36 (Nota 3)	Slaved Gyro - RMI	EXTANT AEROSPACE	670-0001-001
424	424-XXX	AIM400/800	RMI 36 (Nota 3)	Slaved Gyro - RMI	EXTANT AEROSPACE	670-0001-001
425	289-XXX	AIM400/800	RMI 36 (Nota 3)	Slaved Gyro - RMI	EXTANT AEROSPACE	670-0001-001
426	102-0074-03	RCA22-15	RCA 22()	GYRO HORIZON	KELLY / R.C. ALLEN INSTR	1350
427	102-0045-01	RCA26BK-1	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
428	102-0045-02	RCA26BK-1	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
429	102-0047-01	RCA26CM-1	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
430	102-0047-02	RCA26CM-3	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
431	102-0050-01	RCA26BK-8	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
432	102-0050-02	RCA26BK-8	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
433	102-0051-01	RCA26BK-2	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
434	102-0051-02	RCA26BK-2	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
435	102-0051-04	RCA26BK-20	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
436	102-0052-01	RCA26C-5	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
437	102-0052-02	RCA26C-5	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
438	102-0053-01	RCA26AK-1	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
439	102-0053-02	RCA26AK-1	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
440	102-0053-03	RCA26AK-6	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
441	102-0053-04	RCA26AK-6	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
442	102-0054-01	RCA26BK-3	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
443	102-0054-02	RCA26BK-3	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
444	102-0054-03	RCA26BK-12	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
445	102-0054-04	RCA26BK-12	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
446	102-0054-05	RCA26BK-18	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
447	102-0054-06	RCA26BK-31	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
448	102-0054-07	RCA26BK-31	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
449	102-0055-01	RCA26BK-4	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
450	102-0055-02	RCA26BK-4	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
451	102-0057-01	RCA26BK-6	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
452	102-0057-02	RCA26BK-6	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
453	102-0059-01	RCA26BK-7	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
454	102-0059-02	RCA26BK-7	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
455	102-0060-01	RCA26BK-9	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
456	102-0060-02	RCA26BK-9	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
457	102-0060-03	RCA26BK-29	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
458	102-0060-04	RCA26BK-29	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
459	102-0060-11	RCA26BK-34	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
460	102-0060-12	RCA26BK-34	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
461	102-0060-15	RCA26BK-36	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
462	102-0060-16	RCA26BK-36	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
463	102-0061-01	RCA26AK-2	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
464	102-0061-02	RCA26AK-2	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
465	102-0064-01	RCA26AK-4	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
466	102-0064-02	RCA26AK-4	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
467	102-0065-01	RCA26BK-10	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
468	102-0065-02	RCA26BK-10	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
469	102-0066-01	RCA26AK-3	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
470	102-0066-02	RCA26AK-3	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
471	102-0070-01	RCA26CM-2	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
472	102-0070-06	RCA26CM-6	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
473	102-0072-01	RCA26C-7	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
474	102-0072-02	RCA26C-7	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
475	102-0074-03	RCA26C-15	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
476	102-0076-01	RCA26C-8	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
477	102-0076-02	RCA26C-9	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
478	102-0079-01	RCA26BK-21	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
479	206-075-607-103	RCA26BK-12	RCA 26()	INDICATOR, GYRO ATTITUDE	KELLY / R.C. ALLEN INSTR	1317
480	2587335-11	VG 311	VG 31X	VERTICAL GYRO	HONEYWELL	CP 067
481	2587335-12	VG 312	VG 31X	VERTICAL GYRO	HONEYWELL	CP 067
482	2587335-11	VG 313	VG 31X	VERTICAL GYRO	HONEYWELL	CP 067
483	222-375-033-103	4300-8765-1L	4300 (Series)	Artificial Horizon	MID CONTINENT	34-20-02
484	4300-8765-3L	4300-8765-3L	4300 (Series)	Artificial Horizon	MID CONTINENT	34-20-02
485	4300-6980L	4300-6980L	4300 (Series)	Artificial Horizon	MID CONTINENT	34-20-02
486	7000622-902	VG-14A	VG-14()	VERTICAL GYRO	HONEYWELL	A09-3224-002
487	7000622-901	VG-14A	VG-14()	VERTICAL GYRO	HONEYWELL	A09-3224-002
488	4019286-901	VG-14H	VG-14()	VERTICAL GYRO	HONEYWELL	A09-3224-01
489	4019286-902	VG-14H	VG-14()	VERTICAL GYRO	HONEYWELL	A09-3224-01
490	4019286-903	VG-14H	VG-14()	VERTICAL GYRO	HONEYWELL	A09-3224-01

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
491	066-03064-000X	KEA 129	KEA 129	ENCODER ALTIMETER	BENDIX/KING	TM-5035
492	5035P2-P44	KEA 129	KEA 129	ENCODER ALTIMETER	BENDIX/KING	TM-5035
493	066-03062-000X	KEA 346	KEA 346	ENCODER ALTIMETER	BENDIX KING	006-05514-0002
494	066-03062-0010	KEA 346	KEA 346	ENCODER ALTIMETER	BENDIX KING	006-05514-0002
495	066-03062-0011	KEA 346	KEA 346	ENCODER ALTIMETER	BENDIX KING	006-05514-0002
496	066-03062-0012	KEA 346	KEA 346	ENCODER ALTIMETER	BENDIX KING	006-05514-0002
497	066-3064-0X	KEA 130	KEA 130	ENCODER ALTIMETER	BENDIX KING	006-15557-0001
498	5035P2-P2X	5035P	5035 (series)	ENCODER ALTIMETER	UNITED INSTRUMENTS INC	TM-5035
499	5035P2-P30	5035P	5035 (series)	ENCODER ALTIMETER	UNITED INSTRUMENTS INC	TM-5035
500	5035P2-P39	5035P	5035 (series)	ENCODER ALTIMETER	UNITED INSTRUMENTS INC	TM-5035
501	5035P2-P42	5035P	5035 (series)	ENCODER ALTIMETER	UNITED INSTRUMENTS INC	TM-5035
502	5035P2B-P158	5035P	5035 (series)	ENCODER ALTIMETER	UNITED INSTRUMENTS INC	TM-5035
503	5035P2B-P159	5035P	5035 (series)	ENCODER ALTIMETER	UNITED INSTRUMENTS INC	TM-5035
504	5035P2-P41	5035P	5035 (series)	ENCODER ALTIMETER	UNITED INSTRUMENTS INC	TM-5035
505	5035P2-P50	5035P	5035 (series)	ENCODER ALTIMETER	UNITED INSTRUMENTS INC	TM-5035
506	5506-L(xx)	5506-L	5500 (series)	ENCODER ALTIMETER	UNITED INSTRUMENTS INC	34-17-05
507	5506-S(xx)	5506-S	5500 (series)	ENCODER ALTIMETER	UNITED INSTRUMENTS INC	34-17-03
508	B45152-10-013	B45152	B45152-(series)	ENCODER ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
509	B45152-10-113	B45152	B45152-(series)	ENCODER ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
510	B45152-10-013A	B45152	B45152-(series)	ENCODER ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
511	B45152-10-113A	B45152	B45152-(series)	ENCODER ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
512	B45152-10-415	B45152	B45152-(series)	ENCODER ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
513	412-375-010-103	B45152	B45152-(series)	ENCODER ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
514	101420-11226	101420-11225	101420-1122X	ENCODER ALTIMETER	AEROSONIC	FAA FAR 43 App. E
515	101420-11225	101420-11226	101420-1122X	ENCODER ALTIMETER	AEROSONIC	FAA FAR 43 App. E
516	18364	18364	18364	ENCODING ALTIMETER	AERITALIA	FAA FAR 43 App. E
517	3A43.xx.xx.xx.xx	3A43	3A43-()	ALTIMETER	THOMMEN	FAA FAR 43 App. E
518	3A67.xx.xx.xx.xx	3A67	3A67-()	ENCODER ALTIMETER	THOMMEN	FAA FAR 43 App. E
519	8.040.008.1	8.040.008.1	8.040.008.1	ALTIMETER	AERITALIA	FAA FAR 43 App. E
520	B45531-10-10	B45531-10-10	B45531-10-10	ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
521	C 12	C 12	C 12	ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
522	MS 28044 L1A	MS 28044 L1A	MS 28044 L1A	ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
523	23932	23932	23932	ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
524	AN5760-4B	AN5760-4B	AN5760-4B	ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
525	671CLU-10-038D	671CLU-10-038D	671CLU-10-038D	ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
526	671BK-010	671BK-010	671BK-010	ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
527	671CPX-4-37	671CPX-4-37	671CPX-4-37	ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
528	1845X-4-0	1845X-4-0	1845X-4-0	ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
529	5934(X)-1	5934 (series)	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
530	5934(X)-3	5934 (series)	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
531	5934(XX)-1	5934 (series)	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
532	5934(XX)-3	5934 (series)	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
533	5934PAM-1	5934 (series)	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
534	5934PAM-3	5934 (series)	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
535	5934PAD-1	5934 (series)	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
536	5934PAD-3	5934 (series)	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
537	206-070-263-7	5934M-1	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
538	C661071-0101	5934 (series)	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
539	C661071-0202	5934 (series)	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
540	206-070-263-005	5934-3	5934 (series)	ALTIMETER	UNITED INSTRUMENTS INC	TM-5934
541	C678 4101	C678 4101	C678 4101	ALTIMETER	KOLLSMAN	FAA FAR 43 App. E
542	109 0729 34 3	109 0729 34 3	109 0729 34 3	ALTIMETER	AERITALIA	FAA FAR 43 App. E
543	16050S	16050S	16050S	ALTIMETER	AERITALIA	FAA FAR 43 App. E
544	16052 ()	16052 ()	16052 ()	ALTIMETER	AERITALIA	FAA FAR 43 App. E
545	101735 01456	101735 01456	101735 01456	ALTIMETER	AEROSONIC	FAA FAR 43 App. E

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
546	102220 11886	102220 11886	102220 11886	ALTIMETER	AEROSONIC	FAA FAR 43 App. E
547	10450 (series)	10450 (series)	10450 (series)	ALTIMETER	AEROSONIC	FAA FAR 43 App. E
548	1301 1001	1301 1001	1301 1001	ALTIMETER	AEROSONIC	FAA FAR 43 App. E
549	1456	1456	1456	ALTIMETER	AEROSONIC	FAA FAR 43 App. E
550	APN 171(V)/ID 1346	13 ID 1001-1	13 ID 1001-1	ALTIMETER	AERITALIA	FAA FAR 43 App. E
551	JG 206 D1	13 ID 1001-1	13 ID 1001-1	ALTIMETER	AERITALIA	FAA FAR 43 App. E
552	16032X	16032X	16032X/34	ALTIMETER	AERITALIA	FAA FAR 43 App. E
553	8.040.(XXX).2	16034	16032X/34	ALTIMETER	AERITALIA	FAA FAR 43 App. E
554	109-0729-34-1	16034	16032X/34	ALTIMETER	AERITALIA	FAA FAR 43 App. E
555	101720 01545	101720 01545	101720 01545	ALTIMETER	AEROSONIC	ATP 106
556	212-070-238-007	10035 11424	10035 11424	ALTIMETER	AEROSONIC	ATP 1047-I + Tech Pack
557	214-175-278-101	102200 11850	102200 11850	ALTIMETER	AEROSONIC	1059-I
558	222-305-005-101	AC-702	AC-702	ALTITUDE SENSOR	HONEYWELL	CP061
559	222-305-002-103	AC-702	AC-702	ALTITUDE SENSOR	HONEYWELL	CP061
560	4030182-901	AC-702	AC-702	ALTITUDE SENSOR	HONEYWELL	CP061
561	7000300-901	AS-702	AS-702	AIR SPEED SENSOR	HONEYWELL	CP063
562	4013241-901	AZ-241	AZ-241	AIR DATA COMPUTER	HONEYWELL	A09-3435-004
563	4013241-903	AZ-241	AZ-241	AIR DATA COMPUTER	HONEYWELL	A09-3435-004
564	4013241-931	AZ-241	AZ-241	AIR DATA COMPUTER	HONEYWELL	A09-3435-004
565	7002353-901	AZ-649	AZ-649	Air Data Computer	HONEYWELL	A09-3435-009
566	7002353-902	AZ-649	AZ-649	Air Data Computer	HONEYWELL	A09-3435-009
567	7002353-911	AZ-649	AZ-649	Air Data Computer	HONEYWELL	A09-3435-009
568	7002353-912	AZ-649	AZ-649	Air Data Computer	HONEYWELL	A09-3435-009
569	7002353-913	AZ-649	AZ-649	Air Data Computer	HONEYWELL	A09-3435-009
570	4016341-90X	BA-141	BA-141	AIR DATA COMPUTER	HONEYWELL	A09-2175-015
571	7001648-901	AZ-648	AZ-648	AIR DATA COMPUTER	HONEYWELL	A09-3435-008
572	7001648-902	AZ-648	AZ-648	AIR DATA COMPUTER	HONEYWELL	A09-3435-008
573	7000	7000	7000	RATE OF CLIMB INDICATOR	UNITED INSTRUMENTS	7000
574	7030	7000	7000	RATE OF CLIMB INDICATOR	UNITED INSTRUMENTS	7000
575	7040	7000	7000	RATE OF CLIMB INDICATOR	UNITED INSTRUMENTS	7000
576	7060	7000	7000	RATE OF CLIMB INDICATOR	UNITED INSTRUMENTS	7000 + sup 7060
577	7100	7100	7100	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100
578	7120	7100	7100	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100
579	7130	7100	7100	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100
580	7140	7100	7100	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100
581	7160	7100	7100	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100
582	7120L	7100	7100	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100
583	7130L	7100	7100	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100
584	7140L	7100	7100	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100
585	7160L	7100	7100	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100
586	7020B	7000B	7000B	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7000 + sup. B7000
587	7030B	7000B	7000B	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7000 + sup. B7000
588	7040B	7000B	7000B	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7000 + sup. B7000
589	7060B	7000B	7000B	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7000 + sup. B7000
590	7120B	7100B	7100B	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100 + sup. B7100
591	7130B	7100B	7100B	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100 + sup. B7100
592	7140B	7100B	7100B	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100 + sup. B7100
593	7160B	7100B	7100B	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS	7100 + sup. B7100
594	MS28049-1	8.025.000	8.025.000	RATE OF CLIMB INDICATOR	AERITALIA	PTS.8.052.900.3
595	8.129.003	8.129.003	8.129.003/004	RATE OF CLIMB INDICATOR	AERITALIA	PTS.8.052.900.3
596	8.129.004	8.129.004	8.129.003/004	RATE OF CLIMB INDICATOR	AERITALIA	PTS.8.052.900.3
597	MS28075-1	RCS60-IL	RCS60-IL	RATE OF CLIMB INDICATOR	AEROSONIC	ATP

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
598	212-070-239-1	RC-30-VIL	RC-30-VIL	VERTICAL SPEED INDICATOR	AEROSONIC	ATP
599	C661006-0101	30260-1117	30260-1117	VERTICAL SPEED INDICATOR	AEROSONIC	ATP
600	31230-1127	31230-1127	31230-1127	VERTICAL SPEED INDICATOR	AEROSONIC	ATP 3060-I + TP
601	4013013-90X	VS-200	VS-200	VERTICAL SPEED INDICATOR	HONEYWELL	15-2173-03
602	4013013-91X	VS-200	VS-200	VERTICAL SPEED INDICATOR	HONEYWELL	15-2173-03
603	SLZ906X	SLZ9XXX	SLZ9XXX	VERTICAL SPEED INDICATOR	CARP INDUSTRIES	34-10-05
604	SLZ92XX	SLZ9XXX	SLZ9XXX	VERTICAL SPEED INDICATOR	CARP INDUSTRIES	34-10-05
605	SLZ941X	SLZ9XXX	SLZ9XXX	VERTICAL SPEED INDICATOR	CARP INDUSTRIES	34-10-05
606	SLZ96XX	SLZ9XXX	SLZ9XXX	VERTICAL SPEED INDICATOR	CARP INDUSTRIES	34-10-05
607	SLZ9851	SLZ9XXX	SLZ9XXX	VERTICAL SPEED INDICATOR	CARP INDUSTRIES	34-10-05
608	8.137.0XX	11031X	11031X	AIRSPED INDICATOR	AERITALIA	8.900.900-1/2/3/4
609	8.013.000	8.013.000	8.013.000	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
610	8.014.000	8.014.000	8.014.000	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
611	8.052.000	8.052.000	8.052.000	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
612	MS28021-1	8.076.000	8.076.00X	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
613	MS28021-3	8.076.003	8.076.00X	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
614	MS28021-4	8.076.009	8.076.00X	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
615	8.121.003	8.121.003	8.121.00X	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
616	8.121.004	8.121.004	8.121.00X	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
617	8.121.006	8.121.006	8.121.00X	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
618	S-15-KA	MS-28045T1	8.001.001/3	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
619	MS-28045T2	MS-28045T2	8.001.001/3	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
620	8.001.003	MS-28045T2	8.001.001/3	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
621	8.001.001	MS-28045T1	8.001.001/3	AIRSPED INDICATOR	AERITALIA	PTS 8.052.900.3
622	20240-1148	20240-1148	20240-11XX	AIRSPED INDICATOR	AEROSONIC	ATA 34-10 20240 OHM
623	C661063-0103	20240-1189	20240-11XX	AIRSPED INDICATOR	AEROSONIC	ATA 34-10 20240 OHM
624	AW2837AC03	20240-1189	20240-11XX	AIRSPED INDICATOR	AEROSONIC	ATA 34-10 20240 OHM
625	412-075-009-105	20015-11187	20015-11187	AIRSPED INDICATOR	AEROSONIC	ATP 271-I
626	12315-A1	12315-A1	12315-A1	AIRSPED INDICATOR	UNITED INSTRUMENTS	12315B
627	8000	8000	8000	AIRSPED INDICATOR	UNITED INSTRUMENTS	8000B, TM-8000
628	8025	8000	8000	AIRSPED INDICATOR	UNITED INSTRUMENTS	8000B, TM-8000
629	8030	8000	8000	AIRSPED INDICATOR	UNITED INSTRUMENTS	8000B, TM-8000
630	206-075-725-1	8000	8000	AIRSPED INDICATOR	UNITED INSTRUMENTS	8000B, TM-8000
631	369D24506-3	8000	8000	AIRSPED INDICATOR	UNITED INSTRUMENTS	8000B, TM-8000
632	369D24506-7	8000	8000	AIRSPED INDICATOR	UNITED INSTRUMENTS	8000B, TM-8000
633	369H4506-503	8000	8000	AIRSPED INDICATOR	UNITED INSTRUMENTS	8000B, TM-8000
634	8040	8000	8000	AIRSPED INDICATOR	UNITED INSTRUMENTS	8000B, TM-8000
635	8100	8100	8100	AIRSPED INDICATOR	UNITED INSTRUMENTS	8100B, TM-8000
636	8125	8100	8100	AIRSPED INDICATOR	UNITED INSTRUMENTS	8100B, TM-8000
637	8130	8100	8100	AIRSPED INDICATOR	UNITED INSTRUMENTS	8100B, TM-8000
638	8140	8100	8100	AIRSPED INDICATOR	UNITED INSTRUMENTS	8100B, TM-8000
639	8220	8200	8200	AIRSPED INDICATOR	UNITED INSTRUMENTS	8200A
640	8230	8200	8200	AIRSPED INDICATOR	UNITED INSTRUMENTS	8200A
641	8235	8200	8200	AIRSPED INDICATOR	UNITED INSTRUMENTS	8200A
642	8240	8200	8200	AIRSPED INDICATOR	UNITED INSTRUMENTS	8200A
643	1A250-1A	1A250-()	XAXXX-() ; XBXXX-()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0001
644	999-8001-08-1	1A250-()	XAXXX-() ; XBXXX-()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0001
645	1A250-1B	1A250-()	XAXXX-() ; XBXXX-()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0001
646	1A250-1BF	1A250-()	XAXXX-() ; XBXXX-()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0001
647	1A250-1C	1A250-()	XAXXX-() ; XBXXX-()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0001
648	1A250-1D	1A250-()	XAXXX-() ; XBXXX-()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0001
649	2B350-XX	2B350-XX	XAXXX-() ; XBXXX-()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
650	2B250-XX	2B250-XX	XAXXX-() ; XBXXX-()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006

Avionica SPA

Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
651	2A125-XX	2A125-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
652	2A50-XX	2A50-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
653	1B350-XX	1B350-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
654	1B250-XX	1B250-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
655	1A125-XX	1A125-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
656	1A50-XX	1A50-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
657	2A50-XX	2A50-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
658	3A50-XX	3A50-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
659	3A125-XX	3A125-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
660	2A250-XX	2A250-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
661	3A250-XX	3A250-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
662	2A350-XX	2A350-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
663	3A350-XX	3A350-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
664	1B375-XX46860-1000	1B375-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
665	2A375-XX	2A375-XX	XAXXX(-); XBXXX(-)	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	1-001-4902-0006
666	1-001-0102-0085	1B800-1G	1B800()	STATIC INVERTER	AVIONIC INSTRUMENTS	1-001-4902-0007
667	1-001-0102-0084	1B1000-1G	1B1000()	STATIC INVERTER	AVIONIC INSTRUMENTS	1-001-4902-0007
668	1-001-0102-0296	1B1000-1GS	1B1000()	STATIC INVERTER	AVIONIC INSTRUMENTS	1-001-4902-0007
669	1-001-0102-0083	2A1000-1G	2A1000()	STATIC INVERTER	AVIONIC INSTRUMENTS	1-001-4902-0007
670	1-001-0102-0095	2A1000-1AL	2A1000()	STATIC INVERTER	AVIONIC INSTRUMENTS	1-001-4902-0007
671	1-001-0102-0086	3A1000-1G	3A1000()	STATIC INVERTER	AVIONIC INSTRUMENTS	1-001-4902-0007
672	PC-15()	PC-15()	PC-15()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	PC-15 IM
673	PC-17	PC-17	PC-17()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	24-20-25
674	PC-17-1	PC-17	PC-17()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	24-20-25
675	PC-17-2	PC-17	PC-17()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	24-20-25
676	PC-17-3x	PC-17	PC-17()	STATIC INVERTER	AVIONIC INSTRUMENTS Inc.	24-20-25
677	PC-250-1A	PC-250-1A	PC-250	STATIC INVERTER	AVIONIC INSTRUMENTS	24-20-03
678	PC-250-1B	PC-250-1B	PC-250	STATIC INVERTER	AVIONIC INSTRUMENTS	24-20-03
679	PC-250-1C	PC-250-1C	PC-250	STATIC INVERTER	AVIONIC INSTRUMENTS	24-20-03
680	PC-250-2A	PC-250-2A	PC-250	STATIC INVERTER	AVIONIC INSTRUMENTS	24-20-03
681	PC-350	PC-350	PC-350	STATIC INVERTER	AVIONIC INSTRUMENTS	24-20-04
682	501-1228-0X	PS-835()	PS-835()	STATIC INVERTER	JET - L3	TP-329
683	109-0729-44-109	1.500(A)	1.500(A)	Inverter Monitoring Change-Over Box	OCEM	M. M. 1.500 (A)
684	04-1120-0014	ACL-900	ACL-900/920	ANTICOLLISION LIGHT	EMTEQ	ACL900/920 SM
685	04-1120-0028	ACL-920	ACL-900/920	ANTICOLLISION LIGHT	EMTEQ	ACL900/920 SM
686	209-075-326-1	2260-1001-1	2260-1001-1	RMP LIM WARNING DET MOD	NORTHROP CORP.	T.O. 8D15-12-2-3
687	214-074-280-103	214-074-280-103	214-074-280-103/7	RMP LIM DETECTOR	TEXTRON	T.B. 412-92-105
688	214-074-280-107	214-074-280-107	214-074-280-103/7	RMP LIM DETECTOR	TEXTRON	T.B. 412-92-105
689	1372-1-101	RBE16-1	RBE16-1	RMP LIMIT WARNING DETECTOR	LOGIC	A2829-8D15-12-1-2
690	209-075-326-1	RBE16-1	RBE16-1	RMP LIMIT WARNING DETECTOR	LOGIC	A2829-8D15-12-1-2
691	412-075-010-105	3943333-9001	3943333-9001/2	TRIPLE TACHOMETER IND.	BENDIX	81-01 (77-10-02)
692	412-075-010-109	3943333-9002	3943333-9001/2	TRIPLE TACHOMETER IND.	BENDIX	81-01 (77-10-02)
693	212-075-037-101	3751262-5108	3751262-510X	TACHOMETER INDICATOR	BENDIX	74-155
694	212-075-037-103	3751262-5109	3751262-510X	TACHOMETER INDICATOR	BENDIX	74-155
695	3751262-5101	3751262-5101	3751262-510X	TACHOMETER INDICATOR	BENDIX	74-155
696	212-8300-19-1	9813-25-12	9813-25	DUAL TORQUEMETER IND.	LITTON (MOOG)	65-60-01
697	212-8300-19-2	9813-25	9813-25	DUAL TORQUEMETER IND.	LITTON (MOOG)	65-60-01
698	212-8300-19-3	9813-25-13	9813-25	DUAL TORQUEMETER IND.	LITTON (MOOG)	65-60-01
699	412-075-008-101	9813-25-15	9813-25	DUAL TORQUEMETER IND.	LITTON (MOOG)	65-60-01
700	412-075-008-111	9813-25-21	9813-25	DUAL TORQUEMETER IND.	LITTON (MOOG)	65-60-01
701	9813-25-XX	9813-25	9813-25	DUAL TORQUEMETER IND.	LITTON (MOOG)	65-60-01
702	8DJ150XAX1	8DJ150	8DJ150 (series)	TACHOMETER INDICATOR	AMETEK	77-10-44
703	8DJ150XAX2	8DJ150	8DJ150 (series)	TACHOMETER INDICATOR	AMETEK	77-10-44
704	212-070-108-7	15DA03D	212-070-108-X	TACHOMETER INDICATOR	FAREM	E149XX
705	212-070-108-5	15DA03D	212-070-108-X	TACHOMETER INDICATOR	FAREM	E149XX

Avionica SPA
Capability List (AER(EP).P-145)

#	P/N	TYPE	CAPABILITY	DESCRIZIONE	COSTRUTTORE	CODICE MANUALE
706	0201-KAM/5	0201-KAM/5	0201-KAM/5	BRIDGE AMPLIFIER	SMITHS INDUSTRIES / GE	28-46-98
707	0802KAM-08	0802KAM-08	0802-KAM-0X	FUEL GAUGE AMPLIFIER	SMITHS INDUSTRIES / GE	28-47-35
708	0802KAM-09	0802KAM-09	0802-KAM-0X	FUEL GAUGE AMPLIFIER	SMITHS INDUSTRIES / GE	28-47-35
709	393008-0XX	393008	393008-0XX	INDICATOR FOR GAGE FUEL QTY C	SIMMONDS PRECISION	PD 2033C

Nota 1 - per questi apparati verrà richiesta al cliente la documentazione aggiornata, o una dichiarazione scritta comprovante che i documenti tecnici in possesso di Avionica sono aggiornati, oppure che l'ordine di lavoro fornito dal Cliente includa lo stato di aggiornamento delle istruzioni di manutenzione da utilizzare per la parte

Nota 2 -
Eventuali ricambi saranno approvvigionati o dal produttore della parte di ricambio, se il subfornitore è rintracciabile dalla documentazione del costruttore dell'apparato, o da fornitori qualificati secondo le procedure aziendali (MOE parte 2 cap.1)

Nota 3 - apparato simile per tipologia, funzione, tecnologia, al p/n RMI-36 Rockwell Collins